Satel^{*}

BRACKET E-2A

BRACKET E-2A is part of the **BRACKET E** ceiling-and-wall mount distance holder.

The insert allows mounting the AGATE/AOCD-260 devices:

- directly on flat surface
- on the **BRACKET A / BRACKET B** holder.

The **BRACKET E–6** tamper sensor is mounted on the insert.

The BRACKET E-2A insert can be mounted on the **BRACKET E-1** (GY) body.



