

# HOLDER A2

The holder for the PC board of the **ACU-280 ABAX 2** wireless system controller is designed for mounting inside the **OPU-4 P** enclosure. It makes the installation quicker and neater, while keeping the controller at some distance from the wall can have a positive effect on the quality of radio communication with wireless devices.

- for mounting the **ACU-280** controller inside the **OPU-4 P** enclosure
- simple and neat installation

