

# PIN5/RJ-TTL

PIN5/RJ-TTL is a cable for connecting ports of ETHM-1 and ETHM-1 Plus modules with RJ sockets of VERSA control panels.

- cable to connect **ETHM-1** and **ETHM-1 Plus** modules to the **VERSA** central control panel

